# **Securing Processor Architectures**



Jakub Szefer Associate Professor Dept. of Electrical Engineering Yale University

#### Tutorial co-located with ASPLOS 2021 – April 15, 2021

# Outline

- Information Leaks in Processors
- Transient Execution Attacks in Processors


# Design of Trusted Execution Environments

- Secure Processor Architectures
- Memory Protections in Secure Processors
- Multiprocessor and Many-core Secure Processors
- Designing Secure Processors
- Wrap-up and Conclusion



# **Secure Processor Architectures**





# **Processor Security and Secure Processors**

Processor security focuses on ensuring **Confidentiality**, **Integrity**, and **Availability** from attacks by intelligent adversaries


- Reliability or fault tolerance is about random errors
- Security is about "smart" attackers

#### **Course focus: architecture and hardware**

- Many attacks exist on software
- Focus on attacks abusing hardware

# Secure processors:

- Subset of processors with extra security features
- Provide extra logical isolation for software
- But vulnerable to similar attacks as regular processors







Secure Processor Architectures extend a processor with hardware (and related software) features for protection of software

- Protected pieces of code and data are now commonly called Enclaves
  - But can be also Trusted Software Modules
- Focus on the main processor in the system
  - Others focus on co-processors, cryptographic accelerators, or security monitors
- Add more features to isolate secure software from other, untrusted software
  - Includes untrusted Operating System or Virtual Machines
  - Many also consider physical attacks on memory
- Isolation should cover all types of possible ways for information leaks
  - Architectural state
  - Micro-architectural state
  - Due to spatial or temporal sharing of hardware

Most recent threats, i.e. Spectre, etc.

Side and covert channel threats




#### Starting with a typical baseline processor, many secure architectures have been proposed

Starting in late 1990s or early 2000s, academics have shown increased interest in secure processor architectures:

XOM (2000), AEGIS (2003), Secret-Protecting (2005), Bastion (2010), NoHype (2010), HyperWall (2012), Phantom (2013), CHERI (2014), Sanctum (2016), Keystone (about 2017), Ascend (2017), MI6 (2018)


Commercial processor architectures have also included security features:

LPAR in IBM mainframes (1970s), Security Processor Vault in Cell Broadband Engine (2000s), ARM TrustZone (2000s), Intel TXT & TPM module (2000s), Intel SGX (mid 2010s), AMD SEV (late 2010s) Typical computer system with no secure components nor secure processor architectures considers all the components as trusted:





Typical computer system uses ring-based protection scheme, which gives most privileges (and most trust) to the lowest levels of the system software:



Compromised or malicious **OS** can attack all the applications in the system.

Compromised or malicious **Hypervisor** can attack all the OSes in the system.


#### Hardware

Image: https://commons.wikimedia.org/wiki/File:Priv\_rings.svg



Modern computer systems define protections in terms of **privilege level** or protection rings, new privilege levels are defined to provide added protections.

- **Ring 3**Application code, least privileged.
- **Rings 2** and **1** Device drivers and other semi-privileged code, although rarely used.
- **Ring 0**Operating system kernel.
- **Ring -1** Hypervisor or virtual machine monitor (VMM), most privileged mode that a typical system administrator has access to.
- Ring -2System management mode (SMM),<br/>typically locked down by processor manufacturer
- **Ring -3** Platform management engine, retroactively named "ring -3", actually runs on a separate management processor.




# Extend Linear Trust to the New Protection Levels

The hardware is most privileged as it is the lowest level in the system.

- There is a linear relationship between protection ring and privilege (lower ring is more privileged)
- Each component **trusts** all the software "below" it


Security Engine (SecE) can be something like Intel's ME or AMD's PSP.





New privileges can be made orthogonal to existing protection rings.

- E.g. ARM's TrustZone's "normal" and "secure" worlds
- Need privilege level (ring number) and normal / secure privilege




Normal



Privileged




Examples of architectures that do and don't have a linear relationship between privileges and protection ring level:





Key to most secure processor architecture designs is the idea of **trusted processor chip** as the security wherein the protections are provided.





The **Trusted Computing Base (TCB)** is the set of hardware and software that is responsible for realizing the TEE:


- TEE is created by a set of all the components in the TCB
- TCB is trusted to correctly implement the protections
- Vulnerability or successful attack on TCB nullifies TEE protections
- TCB is trusted
- TCB may not be trustworthy, if is not verified or is not bug free

The goal of **Trusted Execution Environments (TEEs)** is to provide protections for a piece of code and data from a range of software and hardware attacks.

• Multiple mutually-untrusting pieces of protected code can run on a system at the same time



Different architectures mainly focus on **protecting Trusted Software Modules** (a.k.a. enclaves) or **whole Virtual Machines**.



Some TEEs have support for protecting whole virtual machines.

Other TEEs support Trusted Software Modules, a.k.a. enclaves



Security properties for the TEEs that secure processor architectures aim to provide:

- Confidentiality
- Integrity


Confidentiality is the prevention of the disclosure of secret or sensitive information to unauthorized users or entities.

Integrity is the prevention of unauthorized modification of protected information without detection.

• Availability is usually not provided usually

Confidentiality and integrity protections are from attacks by other components (and hardware) not in the TCB. There is typically no protection from malicious TCB.

Secure processor architectures break the linear relationship (where lower level protection ring is more trusted):




© Jakub Szefer 2021



Protected software's **state** is distributed throughout the processor. All of it needs to be protected from the untrusted components and other (untrusted) protected software.


- Protect memory through encryption and hashing with integrity trees
- Flush state, or isolate state, of functional units in side processor cores
- Isolate state in uncore and any security modules
- Isolate state in I/O and other subsystems





Secure processor architectures ideally have **no side-effects which are visible to the untrusted components** whenever protected software is executing.

- 1. System is in some state before protected software runs
- 2. Protected software runs modifying system state
- 3. When protected software is interrupted or terminates the all architectural and micro-architectural state modifications should be erased




The software (code and data) executing within TEE protections is assumed to be benign and not malicious:

- Goal of Secure Processor Architectures is to create minimal TCB that realizes a TEE within which the protected software resides and executes
- Secure Processor Architectures can not protect software if it is buggy or has vulnerabilities

Code bloat endangers invalidating assumptions about benign protected software.

Attacks from within protected software should be defended.

Key parts of the hardware TCB can be implemented as dedicated circuits or as firmware or other code running on dedicated processor





Trustworthiness of the TCB depends on the ability to monitor the TCB code (hardware and software) execution as the system runs.

# TCB should be monitored to ensure it is trustworthy.

Monitoring of TCB requires mechanisms to:


- Fingerprint and authenticate TCB code
- Monitor TCB execution
- Protect TCB code (on embedded security processor)
  - Virtual Memory, ASLR, ...


# **Root of Trust for TCB**

Security of the system is derived from a **root of trust**.

- A secret (cryptographic key) only accessible to TCB components
- Derive encryption and signing keys from the root of trust

Hierarchy of keys can be derived from the root of trust








# **Root of Trust and Processor Key**

Each processor requires a unique secret.

- Burn in at the factory by the manufacturer (but implies trust issues with manufacturer and the supply chain)
  - E.g. One-Time Programmable (OTP) fuses
- Use **Physically Uncloneable Functions** (but requires reliability)
  - Extra hardware to derive keys from PUF
  - Mechanisms to generate and distribute certificates for the key





#### Securing Processor Architectures Tutorial – ASPLOS 2021 © Jakub Szefer 2021

https://www.emojione.com/emoji/1f3ed https://www.emojione.com/emoji/1f469-1f4bc https://www.emojione.com/emoji/1f3e2 **26** 

Emoji Image:

# **Derived Keys and Key Distribution**

Need infrastructure!


Derived form the root of trust are signing and verification keys.

• Public key,  $K_{PK}$ , for encrypting data to be sent to the processor Data handled by the TCB Cert ID, K<sub>PK</sub> • Signature verification key,  $K_{VK}$ , for checking Cert Cert data signed by the processor ID  $ID, K_{VK}$ ID, K<sub>PK</sub> TCB can sign user keys **Processor Chip** Cert  $ID, K_{VK}$  Key distribution for PUF based ID KR designs will be different **K**SigK **K**<sub>SK</sub>





With an embedded signing key, the software running in the TEE can be "measured" to attest to external users what code is running on the system.



# **Using Software Measurement**

#### Trusted / Secure / Authenticated Boot:

- Abort boot when wrong measurement is obtained
- Or, continue booting but do not decrypt secrets
- Legitimate software updates will change measurements, may prevent correct boot up

#### **Remote attestation:**

• Measure and digitally sign measurements that are sent to remove user

# Data sealing (local or remote):

• Only unseal data if correct measurements are obtained

#### **TOC-TOU** attacks and measurements:

- Time-of-Check to Time-of-Use (TOC-TOU) attacks leverage the delay between when a measurement is taken, and when the component is used
- Cannot easily use hashes to prevent TOC-TOU attacks



# **Continuous monitoring** is potential solution to TOC-TOU:

- Constantly measure the system, e.g. performance counters, and look for anomalies
- Requires knowing correct and expected behavior of system
- Can be used for continuous authentication

Attacker can "hide in the noise" if they change the execution of the software slightly and do not affect performance counters significantly.






# **Memory Protections in Secure Processors**

Memory is vulnerable to different types of attacks:

- a) Untrusted software running no the processor
- b) Physical attacks on the memory bus, other devices snooping on the bus, man-in-the-middle attacks with malicious device
- c) Physical attacks on the memory (Coldboot, ...)
- d) Malicious devices using DMA or other attacks



Common attack types:

- Snooping
- Spoofing
- Splicing
- Replay
- Disturbance



Different types of attacks exist (very similar to attacks in network settings):

Snooping

Spoofing

Splicing

Replay

• Disturbance

Passive attack, try to read data contents.

Active attack, inject new memory commands to try to read or modify data.

Active attack, combine portions of legitimate memory commands into new memory commands (to read or modify data).

Active attack, re-send old memory command (to read or modify data).


Active attack, DoS on memory bus, repeated memory accesses to age circuits, repeated access to make Rowhammer, etc.



Contents of the memory can be protected with encryption. Data going out of the CPU is encrypted, data coming from memory is decrypted before being used by CPU.


- a) Encryption engine (usually AES in CTR mode) encrypts data going out of processor chip
- b) Decryption engine decrypts incoming data

Pre-compute encryption pads, then only need to do XOR; speed depends on how well counters are fetched / predicted.





Hash tree (also called Merkle Tree) is a logical three structure, typically a binary tree, where two child nodes are hashed together to create parent node; the root node is a hash that depends on value of all the leaf nodes.




Memory blocks can be the leaf nodes in a Merkle Tree, On-chip (cached) nodes are the tree root is a hash that depends assumed trusted, used to on the contents of the memory. speed up verification. Cache Processor Tree Root Chip Boundary Merkle Tree (MT) MT Nodes Counters Data Main Off-Chip Memory Hash tree nodes are stored in Counters included in are (untrusted) main memory. hashes for freshness.

# **Integrity Protection with Bonsai Hash Trees**



Message Authentication Codes (MACs) can be used instead of hashes, and a smaller "Bonsai" tree can be constructed.



Main Off-Chip Memory

## **Integrity Protection of Selected Memory Regions**

- For encryption, type of encryption does not typically depend on memory configuration
- For integrity, the integrity tree needs to consider:
  - Protect whole memory
  - Protect parts of memory (e.g. per application, per VM, etc.)


Memory

• Protect external storage (e.g. data swapped to disk)

E.g., Bastion's memory integrity tree (Champagne, et al., HPCA '10)







Data on Disk

## Security of Non-Volatile Memories and NVRAMs



- Non-volatile memories (NVMs) can store data even when there is no power
- Non-volatile random-access memory (NVRAM) is a specific type of NVM that is suitable to serve as a computer system's main memory, and replace or augment DRAM
- Many types of NVRAMs:
  - ReRAM based on memristors, stores data in resistance of a dialectric material
  - FeRAM uses ferroelectric material instead of a dialectric material
  - MRAM uses ferromagnetic materials and stores data in resistance of a storage cell
  - PCM typically uses chalcogenide glass where different glass phases have different resistances

#### Security considerations

- Data remanence makes passive attacks easier (e.g. data extraction)
- Data is maintained after reboot or crash (security state also needs to be correctly restored after reboot or crash)

Image:


# Features of Systems using NVRAMs

#### **Persistence:**

- Data persists across reboots and crashes, possibly with errors
- Need atomicity for data larger than one memory word (either all data or no data is "persisted")
  - E.g. Write Pending Queue (WPQ) memory controller has non-volatile storage or enough stored charge to write pending data back to the NV-DIMM or NVRAM

### Granularity of persistence:

- Hide non-volatility from the system: simply use memory as DRAM replacement
- Expose non-volatility to the system: allow users to select which data is non-volatile
  - Linux support through Direct Access (DAX) since about 2014
  - Developed for NV-DIMMs (e.g., battery backed DRAM, but works for NVRAMs)



https://www.usenix.org/system/files/login/articles/login\_summer17\_07\_rudoff.pdf




## **Integrity Protection of NVRAMs**



- Non-volatile memories (NVMs) can store data even when there is no power, they are suitable to serve as a computer system's main memory, and replace or augment DRAM
  - Data remanence makes passive attacks easier (e.g. data extraction)
  - Data is maintained after reboot or crash (security state also needs to be correctly restored after reboot or crash)


#### Integrity considerations

- Atomicity of memory updates for data and related security state (so it is correct after reboot or a crash)
- Which data in NVRAM is to be persisted (i.e. granularity)




Snooping attacks can target extracting data (protected with encryption) or **extracting access patterns** to learn what a program is doing.

- Easier in Symmetric multiprocessing (SMP) due to shared bus
- Possible in other configuration if there are untrusted components






Access patterns (traffic analysis) attacks can be protected with use Oblivious RAM, such as Path ORAM. This is on top of encryption and integrity checking.





With 2.5D and 3D integration, the memory is brought into the same package as the main processor chip. Further, with embedded DRAM (eDRAM) the memory is on the same chip.

- Potentially probing attacks are more difficult
- Still limited memory (eDRAM around 128MB in 2017)






## Multiprocessor and Many-core Secure Processors



Symmetric Multi Processing (SMP) and Distributed Share Memory (DSM) also referred to as Non-Uniform Memory Access (NUMA) offer two ways of connecting many CPUs together.



Emoji Image: https://www.emojione.com/emoji/1f479

Encrypt traffic on the bus between processors

- Each source-destination pair can share a hard-coded key
- Or use distribute keys using public key infrastructure (within a computer)

Use MACs for integrity of messages

• Again, each source-destination pair can share a key

Use Merkle trees for memory protection

- Can snoop on the shared memory bus to update the tree root node as other processors are doing memory accesses
- Or per-processor tree



## **DSM / NUMA Protections**

Encrypt traffic on the bus between processors

• Again need a shared key

Use MACs for integrity of messages


• Again, each source-destination pair can share a key

Use Merkle trees for memory protection

• No-longer can snoop on the traffic (DSM is point to point usually)



Trusted processor chip boundary is reduced in most research focusing on many-core security



Emoji Image: https://www.emojione.com/emoji/1f479 With many-core chips, the threats architects worry about start to overlap with hardware security researchers' work

- Untrusted 3<sup>rd</sup> party intellectual property (IP) cores
- Malicious foundry
- Untrusted supply chain


Architecture solutions (add encryption, add hashing, etc.) complement defenses developed by hardware security experts (split manufacturing, etc.).





In addition to the existing assumption about protected memory communication, designs with multiple processors or cores assume the inter-processor communication will be protected:

- Confidentiality
- Integrity
- Communication pattern protection



## **Performance Challenges**

Interconnects between processors are very fast:

- E.g. HyperTransport specifies speeds in excess of 50 GB/s
  - AES block size is 128 bits
  - Encryption would need 3 billion (giga) AES block encryptions or decryptions per second
- Tricks such as counter mode encryption can help
  - Only XOR data with a pad
  - But need to have or predict counters and generate the pads in time





## **Designing Secure Processors**

Four principles for secure processor architecture design based on existing designs and also on ideas about what ideal design should look like are: 

Architectural state

- 1. Protect Off-chip Communication and Memory
- 2. Isolate Processor State among TEE Execution and other Software
- 3. Allow TCB Introspection
- 4. Authenticate and Continuously Monitor TEE and TCB

Additional design suggestions:

- Avoid code bloat
- Minimize TCB
- Ensure hardware security (Trojan prevention, supply chain issues, etc.)
- Use formal verification

- Micro-architectural state
- Due to spatial or temporal sharing of hardware


## **Protect Off-chip Communication and Memory**



Off-chip components and communication are untrusted, need protection with **encryption**, **hashing**, **access pattern protection**.

Open research challenges:

• Performance





When switching among protected software and other software or other protected software, need to flush the state, or save and restore it, to prevent one software influencing another.


Open research challenges:

- Performance
- Finding all the state to flush or clean
- Isolate state during concurrent execution

defend

Spectre

• ISA interface to allow state flushing






Need to ensure correct execution of TCB, through **open access to TCB design**, **monitoring**, **fingerprinting**, and **authentication**.

Open research challenges:

- ISA interface to introspect TCB
- Area, energy, performance costs due extra features for introspection
- Leaking information about TCB or TEE



E.g. open TCB design can minimize attacks on ME or PSP security engines

### 57

## Authenticate and Continuously Monitor TEE and TCB


Monitoring of software running inside TEE, e.g. TSMs or Enclaves, gives assurances about the state of the protected software.

Likewise monitoring TCB ensures protections are still in place.

Open research challenges:

- Interface design for monitoring
- Leaking information about TEE

E.g. continuous monitoring of a TEE can help prevent TOC-TOU attacks.





Hardware





## **Pitfalls and Fallacies**

- Pitfall: Security by Obscurity
- Fallacy: Hardware Is Immutable
- Pitfall: Wrong Threat Model
- Pitfall: Fixed Threat Model
- Pitfall: Use of Outdated or Custom Crypto
- Pitfall: Not Addressing Side Channels
- Pitfall: Requiring Zero-Overhead Security
- Pitfall: Code Bloat
- Pitfall: Incorrect Abstraction

E.g. recent attacks on industry processors.

Most actually realized architectures use a security processor (e.g. ME or PSP).

E.g. original SGX did not claim side channel protection, but researchers attacked it.

Most designs are one-size-fits all solutions.

E.g. today's devices will be in the field for many years, but do not use post-quantum crypto.

Most architectures underestimate side channels.

Performance-, area-, or energy-only focused designs ignore security.

E.g. rather than partition a problem, large code pieces are ran instead TEEs; also TCB gets bigger and bigger leading to bugs.

Abstraction (e.g. ISA assumptions) does not match how device or hardware really behaves.



## **Pitfalls and Fallacies**

٠

. . .

- Pitfall: Allow Access without Authorization
- Pitfall: Defend Only on Speculative Attacks

E.g. Meltdown or recent Micro-architectural Data Sampling (MDS) attacks

E.g. defenses that focus only on timing attacks during speculation



## Outline

- Information Leaks in Processors
- Transient Execution Attacks in Processors

#### Design of Trusted Execution Environments

- Secure Processor Architectures
- Memory Protections in Secure Processors
- Multiprocessor and Many-core Secure Processors
- Designing Secure Processors

#### Wrap-up and Conclusion





# Wrap-up and Conclusion

## Conclusion

- Computer systems are pervasive today
- Attacks on such systems affect privacy and security of users
- **Processor hardware security** focuses on analyzing attacks and defenses
- We have a good and growing understanding of different security threats
- But new attacks keep emerging and need to be mitigated





## Thank You!





Jakub Szefer Associate Professor Dept. of Electrical Engineering Yale University

Related reading...

Jakub Szefer, "**Principles of Secure Processor Architecture Design**," in Synthesis Lectures on Computer Architecture, Morgan & Claypool Publishers, October 2018.



